



SZW-M100J / SZW-M100H / SZW-M100L
SubZero SZW Miniature Digital Wireless System

USER MANUAL

INTRODUCTION

Thank you for purchasing the SubZero Miniature Wireless System.

To help you get the most out of your new instrument, please read this manual carefully.

MAIN FEATURES

2.4GHz Wireless Transmitter

Up to 6 Hours Battery Life

Useful and Versatile System

3.5mm + 6.5mm Jack Connectivity

INSTRUCTIONS

1 - Connect the receiver to the microphone input of your amplifier, mixer, interface or any other microphone input. Use the extra ¼" Jack plug if needed.

2 - Turn the receiver power switch on, the indicator will flash.

3 - Turn on the transmitter, the transmitter and receiver will match automatically, once this has occurred the power indicator will remain on without flashing.

4 - Adjust the volume to a suitable level.

5 - Begin using the microphone.

SPECIFICATIONS

FREQUENCY RANGE: 2.4Ghz

FREQUENCY RESPONSE: 20Hz - 20KHz +/- 3dB

PAIRING METHOD: Automatic Pairing

POWER SUPPLY: Lithium

CURRENT: 0dBm<70mA

CAPSULE TYPE: Condenser

OPERATION DISTANCE: 15m

BATTERY LIFE: 6 Hours

NUMBER OF SELECTABLE CHANNELS: 2

NOTES

The power indicator will show red when power is low, and turns off when less than 10% battery power.

Store the unit in a dry and vented place to avoid from rain, water and heavy movement.

Do not attempt to repair this unit, if you have a problem please contact Gear4music on the information below.

If you have any more questions about this product, please do not hesitate to contact the
Gear4music Customer Service Team on
+44 (0)330 365 4444 or info@gear4music.com